

Resetting Your Cutter

1-1 Reset

- ◆ Turn the vinyl cutter off.
- ◆ Unplug the USB Cable from the computer.
- ◆ Bring the carriage to the middle of the cutter.
- ◆ Turn the vinyl cutter back on.

1-2 Reset

- ◆ There are two red reset buttons on each side of the cutter.
 - Press these buttons simultaneously 5 times.
 - This will reset the cutter's memory.
- ◆ Turn the vinyl cutter back off.

1-3 Reset

- ◆ Pull the power cable out of the cutter.
- ◆ Flip the power switch 3 times with the power cable unplugged.
- ◆ Plug both cables back in and bring the carriage back to the right side.
- ◆ Turn the cutter on.
- ◆ Run a test cut through the software on your computer.

The End

Please review our tutorials for more information on particular features.

<http://www.cutterpros.com/downloads> for further information.

To speak with a technician, submit a ticket at <http://www.cutterpros.com/support/> or call 888-828-8776 x227

CutterPros.com/Hahn Ventures LLC is NOT liable for any software/attachments/instructions/download links/content contained in this presentation. Use the contents of this presentation AT YOUR OWN RISK. CutterPros.com/Hahn Ventures LLC is NOT responsible for any damages incurred to your computer hardware/software or any possible viruses/Trojans/malware or any other type of damaging programs that may be contained in the links and/or attachments. It is your responsibility to verify the contents before using any of the information contained in this presentation. By using the contents in this email you agree to hold CutterPros.com/Hahn Ventures LLC harmless of all liability and damages. You agree that you are totally responsible for what you put on your computer, software you install on your computer and files you download to your computer.

CUTTERPROS.COM