

How to Reset the Cutter

How to reset the cutter to clear the motherboard memory

1. Unplug the USB cable from the computer.
2. Turn vinyl cutter off.
3. Bring the carriage (where the blade holder goes) to the middle of the cutter.
4. Turn vinyl cutter back on.
5. You will see two red reset button on each side of the cutter, press both of these reset buttons 5 times at the same time. This will reset the cutters memory.
6. Turn vinyl cutter back off.
7. Bring carriage back to the right side.
8. Complete your test cut.