

Replacing the knife catch

1. With this one, it can be difficult to remove, you will need to remove the right cover (usb side). There are four Philip screws, two in the front and two in the rear.
2. Once the cover is off, loosen the screw that is attached to the tightening bracket.
3. Then you will need to loosen the top tightening screw that holds the pulley, there is a nut on the bottom, you will need to hold it with the pliers. Then you will need to remove the screw holding the pulley.
4. From here you will need to remove the carriage cover, it can be difficult to remove. Pull from the bottom and work your way up.
5. From here you will need to go to the carriage and remove the two top wheels (long thin flat head screw driver is needed) to release the carriage from the rails.
6. Look for the Allan screw (in the aluminum housing) that hold the knife catch (don't lose the spring and the spring placement pad). You will use the 2.5 mm Allen wrench for the portion.
7. The knife catch should be loose, replace with new one.
8. Reverse instructions to put back together

Tools needed

- Pliers
- Long thin flat head screw driver
- Philip screw driver
- 2.5 mm Allen wrench