

How to uninstall drivers in MAC Computers for FTDI Chipset

To remove the drivers from Mac OS X, the user must be logged on as root.

The easiest way to enable root is to start a terminal session, and type:

Start a Terminal session (Go > Applications > Utilities > Terminal)

and enter the following commands at the command prompt:

```
sudo passwd root
```

You will be prompted for a new password to enable root access, enter in a NEW PASSWORD like 12345

and enter the following commands at the command prompt to remove drivers:

```
cd /System/Library/Extensions
```

```
rm -r FTDI USBSerialDriver.kext
```

```
cd /Library/Receipts
```

```
rm -r FTDI USBSerialDriver.kext
```

The driver will then be removed from the system.

= The light blue color = a SPACE between the letters

To remove the port from the system:

run the application System Preferences and select Network

Selecting Network Port Configurations from the Show menu will display the port as greyed out.

Select the uninstalled port and click Delete. Confirm the deletion to remove the port.